

Samsung Document Camera Scanning Software

NOTE: This software only scans images as graphics. If scanned image has text, you will not be able to edit it in your word processor, e.g. Microsoft Word.

1. Power on the projector and be sure it is set to **RGB1**. (If not, aim the Panasonic remote at the projector and press the RGB button until **RBG1** is displayed on screen.)
2. Power on the doc cam.
3. On the SWITCHER box in the back equipment rack, press the button labeled **PC**.
4. Power on the PC.
5. At the Window desktop, double-click the **SDP900** icon to open the scanning software.
6. When the scanner window opens, place item or document to be scanned on the doc cam. Image will appear in the window. (Takes a few seconds.)
7. Zoom in/out and adjust focus with doc cam buttons (or use the Samsung remote.)
8. When ready to scan, move the cursor to the CAPTURE button (camera icon) in the Control Panel (next to scanner window at right). Click the camera icon with the mouse. Image will be scanned. NOTE: You will not see the image "re-drawn" on screen.
9. To save the image, click on the SAVE button (floppy disk icon) on the Control Panel. You will see a dialogue box where you will enter a filename, choose a graphic format, and choose the drive/directory where the image will be saved. Click OK.
10. Repeat Steps 6-9 to scan and save other images.